

## GDM-357 Operating Manual



### Modern Digital Multimeters


#### I. OVERVIEW

The brand-new GDM-357 is a 2000-count handheld digital multimeter featuring remarkably stable and reliable operation. It is designed with large-scale integrated circuits, a dual integral A/D converter and also offers overload protection for all ranges. The DMM can measure DC&AC voltage, DC&AC current, resistance, capacitance, diode, temperature and continuity, which makes it a perfect solution for your work.










#### II. SAFETY INFORMATION

This instrument is designed and manufactured in compliance with: GB4793, IEC61010-1, IEC1010-2-032, CATII 600V, Pollution Degree 2 and Double Insulation standards.


##### ⚠ Warning

- Please operate the instrument as specified in the manual, otherwise the protection offered by the instrument would be compromised.
- Ensure that it cannot be operated before the back cover is put in place, otherwise there is a risk of electric shock.
- The range switch shall be installed at the correct position.
- Check and ensure the insulation layer of the test leads is in good condition without damage and broken line.
- The red and black test leads should be inserted in the proper terminals and ensured with good contact.
- The input signal is not allowed to exceed the limit value to avoid electric shock and damage.
- Switching the range is strictly prohibited during the measurement of voltage and current in order to avoid damaging the instrument.
- Use only the replacement fuse with the same model or identical electrical specifications.
- In order to avoid electric shock, the potential difference between common port "COM" and the "⊥" earth is not exceeded 600V.
- When the voltage to be measured is more than 60 DC or 30 Vrms AC, you must be careful to avoid electric shock.
- When the LCD shows the symbol of , you must change the battery in time to ensure the measuring accuracy.
- Turn off the power after finishing the measurement. If you do not use it for a long time, take out the battery.
- Don't operate this instrument under high temperature or high humidity. Especially, it cannot be stored in damp environment. If the instrument is affected with damp, its performance will be compromised.
- Don't change the circuits of the instrument at random, otherwise, you will damage the instrument and be in danger.
- Clean the instrument casing with slightly damp cloth and mild agent. No abrasives and solvents are allowed.

#### International Electrical Symbols

	Lower battery level		Grounding		Warning
	Buzzer		AC		DC
	Fuse		Double insulation		Diode

#### III. PRODUCT FEATURES

- There are 30 ranges for function selection.
- LCD display with visible zone 63×29mm.
- Over-range indication "1".
- Display Count: 1999.
- Overload protection for the full range.
- Auto Power Off.
- Temperature Range: Working: 0°C ~ 40°C (32°F ~ 104°F); Storage: -10°C ~ 50°C (14°F ~ 122°F).
- Low Battery Indication:  on upper left corner of LCD.
- Data Hold
- Physical dimensions: 186mm x 91mm x 39mm
- Weight: Approximate 300g (Main unit+holster+tilt stand+battery, excluding test leads)

#### IV. TECHNICAL SPECIFICATIONS

Accuracy: ±(n% reading + digit), the guarantee period is 1 year.  
Ambient temperature: 23°C ± 5°C  
Relative humidity: <75%

##### DC voltage

Range	Resolution	Accuracy
200mV	100μV	GDM-357
2 V	1 mV	±(0.5%+1)
20 V	10mV	
200 V	100mV	
600V	1 V	

##### ⚠ Input impedance: 10MΩ for all ranges

Overloading protection: For 200mV range, 600V, DC or AC RMS. For other ranges, 600Vrms or 850V p-p peak value.

##### AC voltage

Range	Resolution	Accuracy
2 V	1 mV	GDM-357
20 V	10mV	±(0.8%+3)
200 V	100mV	
600V	1 V	

##### ⚠ Input impedance: 10 MΩ for all ranges

Frequency range: 45Hz-400Hz  
Overloading protection: 600V rms or 850V p-p peak  
Display: Mean value(RMS value of sinewave)

##### DC current

Range	Resolution	Accuracy
2 mA	1μA	GDM-357
20 mA	10μA	±(0.8%+1)
200 mA	100μA	±(0.8%+1)
10 A	10 mA	±(1.5%+1)
		±(2.0%+5)

##### ⚠ Overloading protection: uA, mA input: 200 mA /600V Φ 5 X 20 mm

A input end: 10A/600V Φ 6 X 25 mm  
Maximum input current: 10A (For current over 5A, measuring time shall not exceed 15 seconds)

Measured voltage drop: 200mV for full range

##### AC current

Range	Resolution	Accuracy
20 mA	10μA	GDM-357
200 mA	100μA	±(1.0%+3)
		±(1.8%+3)
10 A	10 mA	±(3.0%+5)

##### ⚠ Overloading protection: uA, mA input: 200 mA /600V Φ 5 X 20 mm

A input end: 10A/600V Φ 6 X 25 mm  
Maximum input current: 10A (For current over 5A, measuring time shall not exceed 15 seconds)

Measured voltage drop: 200mV for full range  
Display: Mean value (RMS value of sinewave)

##### Resistance

Range	Resolution	Accuracy
200 Ω	0.1 Ω	GDM-357
2 kΩ	1 Ω	±(1.2%+2)
20 kΩ	10 Ω	
200 kΩ	100 Ω	±(1.0%+2)
2 MΩ	1 kΩ	
20 MΩ	10 kΩ	±(1.2%+2)
		±(1.5%+2)

⚠ Open circuit voltage: ≤ 700mV (for range of 200MΩ, the open circuit voltage is about 2.8V).  
Overloading protection: 600V for all ranges, DC or AC RMS.

##### Capacitance

Range	Resolution	Accuracy
2 nF	1 pF	GDM-357
20 nF	10 pF	±(4.0%+3)
200 nF	100 pF	
2 μF	1 nF	
200 μF	100 nF	

≤ 50 μF ±(5.0%+4) > 50μF, for reference only.



##### ⚠ Testing signal: About 400Hz, 40mVrms

Testing is made after discharging the capacitor.

##### Temperature

Range	Resolution	Accuracy
TEMP °C (-40 °C~1000 °C)	-40 °C~0 °C	GDM-357
	0 °C~400 °C	±(3%+9)
	400 °C~1000 °C	±(1%+5)
TEMP °F (-40 °F~1832 °F)	-40 °F~32 °F	±(2%+10)
	32 °F~752 °F	±(3%+10)
	752 °F~1832 °F	±(1%+8)
		±(2 %+18)

##### Continuity and Diodes

Range	Description	Testing conditions
	Display the forward voltage of diode (approximate value), unit "mV"	Forward DC current about 1 mA Reverse DC voltage about 2.8 V
	Resistances: 10Ω, the buzzer sounds; > 10Ω, the buzzer doesn't necessarily sound; Display approximate resistance value, unit: Ω.	Open circuit voltage about 2.8V

⚠ Overloading protection: 600V DC or AC effective value

